

Fleck Stone Pot Instructions

- 1. Spray pot with 2-3 coats of Plasti-kote's Sandable primer. Allow the primer to dry 30-45 minutes before applying the base coat.**
- 2. Using the Ultra Enamel as a base coat, spray a nice even coat holding the can approximately 12 inches away. Allow the pot to dry for about 20 minutes before moving onto the next step.**
- 3. Next apply Fleck Stone's Ancient Ruins. When spraying Fleck Stone, be sure to stand approximately 16 inches away from the pot. Standing too close will blast the spray off of the pot. Apply 2-3 coats allowing 20 minutes in between coats.**
- 4. For best results, apply the Clear Kote once the pot has dried over night. Once the Clear Kote has been applied, the pot should dry for at least 2 hours before handling. Applying Fleck-Stone's Clear Kote will protect your pot from the elements**